

METER ID & ADDING CHANNELS

METER ID:

The Meter ID is the site name used in ETB Monitor. If your site is not yet listed in ETB Monitor, please email sgip@energytoolbase.com.

ADD CHANNEL:

Listed below are the Channel IDs you need to add (4 total) the way they are listed below:

- Channel ID:** Charge # [int]
 - Category:** Electric
 - Unit of measure:** integer

- Channel ID:** Discharge # [int]
 - Category:** Electric
 - Unit of measure:** integer

- Channel ID:** ESS_Energy_Stored [kWh]
 - Category:** Electric
 - Unit of measure:** kWh

- Channel ID:** ESS_Energy_Discharged [kWh]
 - Category:** Electric
 - Unit of measure:** kWh